




ST-i Guiding Kit Assembly Instructions




Step 1

Attach the mounting rings to the universal base plate using the supplied 1/4-20 flat head screws. Make sure that the screw heads set completely into the recesses. Before tightening to the base plate, also make sure that the rings are aligned so that the ST-i body will insert through both rings after it is attached to the telescope.




Step 2

Attach the universal base plate with mounting rings to your (user supplied) telescope piggy back bracket, dovetail accessory plate or other telescope mounting plate.




Step 3

Loosen the hex head bolts in the mounting rings so that the ST-i body slides through both rings. It may be helpful to use a flat blade screwdriver to spread the rings slightly for this step. With the ST-i body in place gently tighten the rings to hold it secure. Do not over-tighten the rings.



Step 4

Screw the special c-mount adapter into the front of the ST-i, then attach the lens. A lens hood is also provided to help eliminate glare from any nearby lights.



Completed Assembly